



LM/LX-100 Sitelink3D

Onboard Weighing

Configuration Manual



LM/LX-100 Sitelink3D Onboard Weighing Configuration Manual

Part Number 1071470-01

Revision A

© 2024, Topcon Corporation

Table of Contents

Preface	iv
Introduction	1-1
System Overview	1-1
Load Weighing Display Description	1-1
Technical Documents	1-1
Settings and Connections	2-1
Settings	2-1
GPS Settings	2-1
Com Port Setting	2-3
Time and Date Setting	2-4
Region Reference Warning	2-5
Auto Triggers	2-7
Auto Trigger Selection by the Application	2-8
Examples of Trigger Use by the Application	2-8
Simulated GPS	2-9
Other Configuration Settings	2-10
Join a Site	2-10
Load Weighing Display Sitelink3D Settings	2-10
Load Weighing Display Sitelink Screen Options	2-13
Ways to Join a Site	2-13
Site Discovery	2-13
Site Identifier	2-14
Nearby Site	2-16
Site Joining Process	2-17
Leave a Site	2-20
Support	3-1
Get Support.	3-1
Site Desk Support	3-1
Configure Organizational Desk Support	3-3
Load Weighing Display	3-3
Sitelink3D	3-6
Make a Remote Support Request	3-9
Dumper and Haul Truck Configuration	4-1
Automatic Mode	4-1
Manual Mode	4-4

Manual Mode with Regions Selection4-5

Add to Total Auto Trigger4-5

Reports5-1

Weight Load Report.5-1

 Create a Weight Load Report5-3

 Work With Weight Load Reports5-6

Live Statistics6-1

Live Statistics Loader Widgets6-1

 Weight Region Summary Widget Creation6-2

 Weight Summary Widget Creation6-5

 Weight Contract Summary Widget Creation6-9

Live Statistics Haul Summary Widget Creation6-12

Data Cloud Synchronization7-1

Automatic References Synchronization7-1

Manual Reference Synchronization7-3

Add Reference Data on the Load Weighing Display7-4

Site Key Expiration7-4

Safety Warnings8-1

General Warnings8-1

Preface

Thank you for purchasing this Topcon product. The materials available in this Manual (the “Manual”) have been prepared by Topcon Positioning Systems, Inc. (“TPS”) for owners of the covered Topcon product (the “Product”), and are designed to assist owners with the Product. Use of the Product is subject to these terms and conditions (the “Terms and Conditions”).



NOTICE

Please read the terms and conditions carefully.

Terms and Conditions

Use

This Product is designed to be used by a professional. The user should have a good knowledge of the safe use of the Product and implement the types of safety procedures recommended by the local government protection agency for both private use and commercial job sites.

Copyrights

All information contained in this Manual is the intellectual property of, and copyrighted material of TPS. All rights are reserved. Do not use, access, copy, store, display, create derivative works of, sell, modify, publish, distribute, or allow any third party access to, any graphics, content, information or data in this Manual without TPS’s express written consent and may only use such information for the care and operation of the Product. The information and data in this Manual are a valuable asset of TPS and are developed by the expenditure of considerable work, time and money, and are the result of original selection, coordination and arrangement by TPS.

Trademarks

Sitelink3D™, Topcon®, and Topcon Positioning Systems™ are trademarks or registered trademarks of TPS. Windows® is a registered trademark of Microsoft Corporation. The Bluetooth® word mark and logos are owned by Bluetooth SIG, Inc. and any use of such marks by Topcon Positioning Systems, Inc. is used under license. Other product and company names mentioned herein may be trademarks of their respective owners.

Disclaimer of Warranty

EXCEPT FOR ANY WARRANTIES IN AN APPENDIX OR A WARRANTY CARD ACCOMPANYING THE PRODUCT, THIS MANUAL AND THE PRODUCT ARE PROVIDED “AS-IS.” THERE ARE NO OTHER WARRANTIES. TPS DISCLAIMS ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR USE OR PURPOSE.

Limitation of Liability

TPS AND ITS DISTRIBUTORS SHALL NOT BE LIABLE FOR TECHNICAL OR EDITORIAL ERRORS OR OMISSIONS CONTAINED HEREIN; NOR FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE FURNISHING, PERFORMANCE OR USE OF THIS MATERIAL OR THE PRODUCT. SUCH DISCLAIMED INCIDENTAL OR CONSEQUENTIAL DAMAGES INCLUDE BUT ARE NOT LIMITED TO LOSS OF TIME, LOSS OR DESTRUCTION OF DATA, DAMAGE TO OR LOSS OF LIVESTOCK AND/OR CROPS, LOSS OF PROFIT, SAVINGS OR REVENUE, OR LOSS USE OF THE PRODUCT.

IN ADDITION, TPS IS NOT RESPONSIBLE OR LIABLE FOR DAMAGES OR COSTS INCURRED IN CONNECTION WITH OBTAINING SUBSTITUTE PRODUCTS OR SOFTWARE, CLAIMS BY OTHERS, INCONVENIENCE, OR ANY OTHER COSTS. IN ALL CASES, TPS SHALL HAVE NO LIABILITY FOR DAMAGES OR OTHERWISE TO YOU OR ANY OTHER PERSON OR ENTITY IN EXCESS OF THE PURCHASE PRICE PAID FOR THE PRODUCT.

License Agreement

Use of any computer programs or software supplied by TPS or downloaded from a TPS website (the “Software”) in connection with the receiver constitutes acceptance of these Terms and Conditions in this Manual and an agreement to abide by these Terms and Conditions. The user is granted a personal, non-exclusive, non-transferable license to use such Software under the terms stated herein and in any case only with a single receiver or single computer. You may not assign or transfer the Software or this license without the express written consent of TPS. This license is effective until terminated. You may terminate the license at any time by destroying the Software and Manual. TPS may terminate the license if you fail to comply with any of the Terms or Conditions. You agree to destroy the Software and manual upon termination of the use of the receiver. All ownership, copyright and other intellectual property rights in and to the Software belong to TPS. If these license terms are not acceptable, return any unused software and manual.

Website; Other Statements

No statement contained at the TPS website (or any other website) or in any other advertisements or TPS literature or made by an employee or independent contractor of TPS modifies these Terms and Conditions (including the Software license, warranty and limitation of liability).

Technical Documentation and Utility Software

Download and open the myTopcon NOW! app on your iOS or Android device or visit the Topcon support website (mytopconnow.topconpositioning.com). Log in to access available manuals, technical and compliance documentation, training material, and utility software to help set up and use your Topcon product.

Safety

Improper use of the Product can lead to injury to persons or property and/or malfunction of the Product. The Product should only be repaired by authorized TPS warranty service centers.

Miscellaneous

The above Terms and Conditions may be amended, modified, superseded, or canceled, at any time by TPS. The above Terms and Conditions will be governed by, and construed in accordance with, the laws of the State of California, without reference to conflict of laws.

Open Source Support

The Topcon TotalCare website contains the licenses and notices for open source software used in this product.

With respect to the free/open source software, if you have any questions or wish to receive a copy of the source code to which you are entitled under the applicable free/open source license(s), such as the GNU Lesser/General Public License, please visit www.topconcare.com/en/support.

Manual Conventions

This manual uses the following conventions:

Convention	Description	Example
Bold	Menu, or dropdown list selection	File > Exit (Select the File menu and select Exit)
	Name of a dialog box or screen	From the Connection screen...
	Button or key commands	Select Finish .
Mono	User supplied text or variable	Type <code>guest</code> , and click Enter .
<i>Italic</i>	Reference to another manual or help document	Refer to the <i>Topcon Reference Manual</i> .



TIP

Notification that one or more steps may be taken to reduce effort, time, and/or expense.



NOTE

Further information to note about system configuration, maintenance, or setup.



NOTICE

Supplementary information that if disregarded can have an adverse effect on system operation, system performance, data integrity, or measurements.



CAUTION

Notification that an action has the potential to result in minor personal injury, system damage, loss of data, or loss of warranty.



WARNING

Notification that an action has the potential to result in personal injury or property damage.



DANGER

Notification that an action has the potential to result in severe personal injury or death.

Introduction

System Overview

Topcon Sitelink3D is a cloud-based database application used to track the material moved on a work site. It stores data from the machines working on the site to the site managers which can be pushed to the LM/LX-100 load weighing display and archived in the cloud. Managers can view real-time data generated by the application. Live statistics widgets can be configured to monitor live shift productivity to make sure that daily targets are met. The same data are used to generate weight reports.

The LM-100 and LX-100 systems include the configurable option to save a list of machine operators. An operator can select their name from the list upon login. When selected, the operator name is linked to all weighing activity and sent to Sitelink3D until another operator logs in. The purpose of this feature is to annotate data. Refer to the LM-100 and LX-100 operators manuals for detailed information.

Load Weighing Display Description

The LM-100 or LX-100 load weighing display is the device used to run the Loadex and Loadmaster applications. The load weighing display can be joined with the Sitelink3D website and synchronizes at startup when connected.

The Loadex and Loadmaster applications can be configured to automatically select loading and dumping regions with GPS positioning, which lets Sitelink3D track the movement of materials around the site.

Technical Documents

The following documents will help to use LM/LX-100 with Sitelink3D:

- *LM-100 Operation Manual*
- *LM-100 On-board Weighing System (WM-L1) Installation Manual*
- *Loadex 100/LX-100 Operation Manual*
- *LX-100 Installation Manual*

Settings and Connections

Settings

LM-100 and LX-100 join with the Sitelink3D cloud service through Ethernet, Wi-Fi, or mobile internet (SIM) and send relevant data from the machine.



GPS Settings

The load weighing display must be configured to get access to Sitelink3D. A PIN is required to access the **Technician Level Settings** menu to configure the interface.



NOTE

PIN is the abbreviation for personal identification number, an identifying number allocated to an individual by the application that is used to validate electronic transactions. The default technician level settings PIN is 1234.

1. Select **Setup**  to open the **Setup** menu.
2. Select **Technician Level Settings**  to open the **Enter Password** dialog (Figure 2-1).
3. Enter a valid PIN using the virtual keypad.
4. Select **ENT** to open the **Technician Level Settings** menu (Figure 2-2 on page 2-2).




Figure 2-1: Load Weighing Display Technician Level Settings Enter Password

5. Select **Printer and Serial Output Setup**, then select **OK** to open the **Printer and Serial Output Setup** screen.




Figure 2-2: Load Weighing Display Technician Level Settings Menu

6. Select **GPS**, then select **Edit** to open the **GPS Options** screen (Figure 2-4 on page 2-3).




Figure 2-3: Load Weighing Display Printer and Serial Output Setup

The **Sync UTC Time** option is enabled by default.




Figure 2-4: Load Weighing Display GPS Options

Com Port Setting

1. If the GPS receiver is connected, set the **Com Port Setting** to COM1:
 - a. Select **GPS** on the **Printer and Serial Output Setup** screen (Figure 2-3 on page 2-2).
 - b. Select **Edit** on the **Printer and Serial Output Setup** screen.
 - c. Select **Com Port Setting** on the **GPS Options** screen (Figure 2-4).
 - d. Select **Edit** on the **GPS Options** screen to open the **Mode** dialog (Figure 2-5 on page 2-4).

- e. Select **COM1**.
 - f. Select **OK**.
2. Select **ESC**.




Figure 2-5: Com Port Mode



NOTE

If the GPS receiver is not connected, see “Simulated GPS” on page 2-9.

Time and Date Setting

1. Select **Time & Date** on the **Technician Level Settings** menu (Figure 2-2 on page 2-2).
2. Select **OK** to open the **Time & Date** screen (Figure 2-6 on page 2-5).

3. Make sure that the time zone is correct on the **Time & Date** screen.




Figure 2-6: Load Weighing Display Time & Date



NOTICE

Sync UTC Time (Figure 2-4 on page 2-3) must always be enabled because the time and date must always be correct.

Region Reference Warning

The region reference warning warns the operator when the machine is detected inside a region where the material is different than the material that was just lifted or manually selected. This prevents a load or dump action in the incorrect region. The region reference warning is disabled by default.

There are two ways to use the warning:

- Select **Region Reference Warning** on the **GPS Settings** screen to enable it (see Figure 2-4 on page 2-3). After the material is picked or loaded, the product is automatically selected on the load weighing display. The operator drives to the dump region. If the dump region has the same material assigned, the box is green (Figure 2-7 on page 2-6). If the dump region has a different material assigned, the box is red (Figure 2-8 on page 2-6).
- The operator can manually select the material from the references list. When the material is selected manually, the region reference warning can be used in the region where the material was picked up or loaded. Upon arrival in the dump region, if the same material is assigned, the box is green. If the dump region has a different material assigned, the box is red.




Figure 2-7: Load Weighing Display Dump Region Green




Figure 2-8: Load Weighing Display Dump Region Red

- Clear the **Region Reference Warning** on the **GPS Settings** screen (Figure 2-4 on page 2-3) to disable it and automatically select the region name and the product when the auto trigger is enabled (see “Auto Triggers” on page 2-7).

Auto Triggers

When the machine enters a geofence region with an auto trigger enabled and the system senses the auto trigger, it tells the system that either a load or dump event is about to occur. There are multiple auto trigger options for the selection of the products, loading regions, and dumping regions.

Table 2-1: Load and Dump Auto Triggers

Auto Trigger	Description
Reverse	Selects the loading region when the reverse gear is engaged (if the reverse gear is connected, Figure 2-9 on page 2-7).
Bucket Sensor	Selects the dump region when the bucket is tipped (if a bucket sensor is fitted, Figure 2-10 on page 2-8).
Add to Total	Selects the dump location as the load is weighed. This option is for the applications without the bucket sensor.
Timer	This option is adjustable and represents the duration (in seconds) in which a machine must be in a region before it is selected. It is based on the Usage setting in Metadata > Regions on the Sitelink3D website (see “Automatic Mode” on page 4-1).
Manual	This trigger is for dump trucks. It lets the operator manually select the regions in which the load has been picked and dumped.



NOTE

The **Add to Total** auto trigger cannot be used with a bucket sensor. To correctly select the geofence regions and products, material must only be weighed at the destination.



NOTE

A geofence is a virtual geographic boundary.




Figure 2-9: Load Weighing Display Load Auto Trigger




Figure 2-10: Load Weighing Display Dump Auto Trigger

Auto Trigger Selection by the Application

When the machine is within a geofence region and the system senses an auto trigger, it tells the system that either a load or dump event is about to occur.

Table 2-2: Load Auto Trigger Selection

Load Trigger	Loader	Loadex	Dumper	Forklift
Reverse	Yes	No	No	Yes
Timer	Yes	Yes	Yes	Yes
Manual	No	No	Yes	No

Table 2-3: Dump Auto Trigger Selection

Dump Trigger	Loader	Loadex	Dumper	Forklift
Bucket sensor	Yes	No	No	No
Timer	Yes	No	Yes	Yes
Manual	No	No	Yes	No
Add to Total	Yes	Yes	Yes	Yes

Examples of Trigger Use by the Application

Wheel Loader

The default triggers are **Reverse** for loading and **Bucket Sensor** for dumping.

The **Timer** trigger can be used to select load and/or dump regions. The **Usage** must be set in **Sitelink > Metadata > Regions** to enable this option. The **Timer** trigger selects the loading region only when it has an assigned **Load** usage. The **Timer** trigger selects the dumping region only when it has an assigned **Dump** usage.

To use the **Reverse** and/or **Bucket sensor** triggers to automate the region/product selection process, the following steps must be done:

1. Before loading, make sure that the previous job is cleared.
2. Load the bucket and reverse the loader.
3. Do not weigh the load until the loader has reversed.
4. Go to the dumping destination.
5. Weigh the bucket, then tip it.

**NOTE**

The **Add to Total** trigger can be used to automatically select the dump region when no bucket sensor is attached. In this case, the weighing routine must be done only at the destination region.

Loadex

The default triggers are **Timer** for loading and **Add To Total** for dumping. Selected triggers are sufficient because machines equipped with Loadex 100/200 systems work when stationary.

Dumper

The system must be configured manually to use Loadmaster with the dumper and haul truck (see “Dumper and Haul Truck Configuration” on page 4-1).

Simulated GPS

This is used to simulate a GPS position when no GPS receiver is connected. The machine shows on the globe in a fixed position. To use Simulated GPS, enter the latitude and longitude of the required location and enable it.

Alternatively, set the GPS Com Port setting to OFF (default setting) before joining the site. The system will then automatically assign the site coordinates to the simulated GPS once the device joins Sitelink3D.

**NOTE**

The Site Desk Support pairing requires a GPS position (simulated or actual).



Other Configuration Settings

Table 2-4: Other Configuration Settings

Receiver Height Offset	Sets the height of the receiver mounting position for the accurate altitude measurement.
Receiver X Offset (m)	Sets the offset for the GPS receiver in meters on the X-axis. From the operator's point of view, a positive number sets the GPS position to the right, and a negative number to the left.
Receiver Y Offset (m)	Sets the offset for the GPS receiver in meters on the Y-axis. From the operator's point of view, a positive number sets the GPS position forward, and a negative number backward.
Min Speed (km/h)	Sets a minimum speed threshold that must be met before a new position is sent to Sitelink3D. This is to minimize false accumulation of distance due to satellite drift.
Distance Slew Inhibit (Loadex only)	This stops the calculation of the traveled distance above the programmable slew speed.

Join a Site

Load Weighing Display Sitelink3D Settings

1. Select **Setup**  to open the **Setup** menu.
1. Select **Operator** menu  to open the **Operator** menu.
2. Select **Diagnostics** to open the **Diagnostics** screen (Figure 2-11).
3. Select **PING**.




Figure 2-11: Load Weighing Display Diagnostics

If the display has an internet connection, a confirmation dialog opens (Figure 2-12).

4. Select **OK**.






Figure 2-12: Success Message

The load weighing display connects to the internet.

5. Select **Setup**  to open the **Setup** menu.
6. Select **Technician Level Settings** .
7. If necessary, use the keypad to enter a valid PIN, then select **ENT**.

The default technician level settings PIN is 1234.

The **Technician Level Settings** menu opens (Figure 2-13).

8. Select **Sitelink**, then select **OK**.




Figure 2-13: Load Weighing Display Technician Level Settings Menu

The **Sitelink Wizard** confirmation dialog opens (Figure 2-14). This dialog only shows when the load weighing display is not joined with the site.

9. Select **SKIP** to skip the wizard, or select **OK** to run the wizard.




Figure 2-14: Load Weighing Display Sitelink Wizard Prompt

When **OK** is selected, the **Join Site** dialog opens (Figure 2-15).

10. Select the appropriate method, then select **OK**.




Figure 2-15: Load Weighing Display Join Site

After the wizard is finished, or if **SKIP** is selected, the **Sitelink** screen opens.




Figure 2-16: Load Weighing Display Sitelink

Load Weighing Display Sitelink Screen Options

Site	Select to join or leave a site.
View Site	Select to view the information about the currently joined site.
Machine Identification Information	Select to view the information about the machine.
Remote Support	Select to configure the Organizational Desk Support.
Site Discovery	Select to enable joining a site by driving into the discoverable region. Note: This feature is only enabled if the device is not joined with any site.
Machines on Site	Select to enable viewing the distance to the other machines or trucks joined with the site, for the ease of identification, that is, correct selection of a truck to load in the proximity.

Ways to Join a Site

The three methods for how to join a site are **Site Discovery**, **Site Identifier**, or **Nearby Site**.

Site Discovery

1. Make sure that **Site Discovery** is enabled (green) on the **Sitelink** menu (see Figure 2-16).
2. Drive into the discoverable region (set in **Sitelink > Metadata > Regions**) used for site discovery.

When the load weighing display detects the site, it prompts the operator to join it.

3. Do the steps described in “Site Joining Process” on page 2-17.

Site Identifier



NOTE

Site Discovery is available when the device has not joined any sites.

1. Open the **Site** menu on the **Sitelink3D** website and select **Site Information** to open the **Site Information** dialog (Figure 2-18).




Figure 2-17: Sitelink3D Site Menu

2. Record the **Discovery ID**.




Figure 2-18: Site Information Discovery ID

3. Select **Site** on the load weighing display **Sitelink** screen (Figure 2-19).
4. Select **OK** on the load weighing display **Sitelink** screen to open the **Join Site** screen (Figure 2-20).




Figure 2-19: Load Weighing Display Sitelink

5. Select **Using the Identifier**.
6. Select **OK**.




Figure 2-20: Load Weighing Display Join Site

When the load weighing display detects the site, it prompts the operator to join it.

7. Do the steps described in "Site Joining Process" on page 2-17.

Nearby Site

This method is the same as “Site Discovery” on page 2-13, except that it can also be used when the load weighing display is already joined with a site.

1. Make sure that **Site Discovery** is enabled (green) on the **Sitelink** menu (see Figure 2-16 on page 2-13).
2. Drive a machine into a discoverable region of the site.
3. Select **Site** on the load weighing display **Sitelink** screen.
4. Select **OK** on the load weighing display **Sitelink** screen to open the **Site** screen (Figure 2-22).




Figure 2-21: Load Weighing Display Sitelink

5. Select **Add** .




Figure 2-22: Load Weighing Display Site

The **Join Site** screen opens (Figure 2-23).

6. Select **Nearby site**.
7. Select **OK**.




Figure 2-23: Load Weighing Display Join Site

When the load weighing display detects the site, it prompts the operator to join it.

8. Do the steps described in “Site Joining Process” on page 2-17.



NOTE

Nearby Site can be used at any time. **Site Discovery** is only available when no site has been joined.

Site Joining Process

After the site joining method is detected (see “Ways to Join a Site” on page 2-13), the LM-100/LX-100 load weighing display guides the operator through the steps to join the site in Sitelink3D. After successfully joining a site, it is possible to view data on Sitelink3D or via API protocol.

The load weighing display prompts the operator to either backup or clear all the stored data. Reference data from all the products, regions, and trucks stored on the load weighing display are cleared after a site change or a site is joined for the first time.



CAUTION

All reference data for systems joined with Sitelink3D are stored in the cloud. All local data are deleted during the site joining process. Backing up local data prior to joining Sitelink3D is **highly recommended**. The backed up data can then be imported after the joining process is complete.

A confirmation dialog opens.




Figure 2-24: All Data Will Be Cleared Dialog

1. Select **OK** to backup, or select **SKIP** to continue without backing up.

If **OK** is selected, the LM-100 or LX-100 exports a *.json file to the USB memory stick.

The **Machine Identification Information** screen opens (Figure 2-25 on page 2-18).



NOTE

The necessary information is in the **Metadata** dialog in Sitelink3D.

2. Enter the machine identification information on the **Machine Identification Information** screen.
3. Select the **Asset Class**:
 - **Wheel Loader** (Loadmaster A100)
 - **Truck** (Loadmaster A100 for dump trucks)
 - **Excavator** (Loadex 100, 200)

Machine Identification Information	
Name <small>RDS</small>	
OEM	
Model	
Serial Number	
Asset Class <small>excavator</small>	

Figure 2-25: Load Weighing Display Machine Identification Information

- If the **Site Identifier** method was used, enter the **Discovery ID** that was recorded in Step 2 on page 14 in the **Enter Site Identifier** dialog.




Figure 2-26: Enter Site Identifier

The **Enter Site Access PIN** dialog opens (Figure 2-27).

- Enter the **Site Access PIN** in the **Enter Site Access PIN** dialog using the virtual keypad.

The **Site Identifier** and **Site Access PIN** can be created in the **Sitelink3D Site Key Manager**.






Figure 2-27: Enter Site Access PIN

After a site is joined, a cloud icon appears on the top bar to show that Sitelink3D is connected to the load weighing display.



Figure 2-28: Sitelink3D Connected Icon

Leave a Site

1. Select **Setup**  to open the **Setup** menu.
2. Select **Technician Level Settings** .
3. If necessary, use the keypad to enter a valid PIN, then select **ENT**.

The default technician level settings PIN is 1234.

The **Technician Level Settings** menu opens.

4. Select **Sitelink**, then select **OK** to open the **Sitelink** screen (Figure 2-29).
5. Select **Site**.
6. Select **OK** to open the **Site** screen (Figure 2-30 on page 2-21).





Figure 2-29: Load Weighing Display Sitelink

7. Select the site to leave, then select **Delete** .
8. Select **OK**.




Figure 2-30: Load Weighing Display Site



NOTE

It is possible that more than one site will show, depending on the environment in which the machine is working.

Get Support

Two Sitelink3D Support Desk options are available from the load weighing display.

Site Desk Support	Provides remote view and control of the load weighing display when paired with the specific site
Organizational Desk Support	Provides remote view, remote control, file transfer, and software update for the load weighing display when paired with the organization

Site Desk Support

Site Desk Support is automatically available when the load weighing display joins the site.

1. Select the **Machines** tab in Sitelink3D.



Figure 3-1: Sitelink3D Machines Tab

2. Select the required option:

- **Remote View**
- **Remote Control**

The **Remote View** option lets the remote operator see a live feed from the load weighing display on the computer screen.




Figure 3-2: Site Desk Remote View

The **Remote Control** option lets the remote operator control the load weighing display from the computer screen.



Figure 3-3: Site Desk Remote Control

3. Enter a message for the remote operator.
4. Select **Support** to pair.



REMOTE VIEW

Please enter a message for the remote operator to request a connection:

This connection will be logged with this message as a description.

Support Cancel

Figure 3-4: Remote Support Connection





NOTE

When Site Desk Support is automatically paired, the message is not sent to the operator when Remote View is used. When Remote Control is used, an optional message can be included that shows on the load weighing display.

Configure Organizational Desk Support

Load Weighing Display

1. Select **Setup**  to open the **Setup** menu.
2. Select **Technician Level Settings** .
3. If necessary, use the keypad to enter a valid PIN, then select **ENT**.

The default technician level settings PIN is 1234.

The **Technician Level Settings** menu opens.

4. Select **Sitelink**, then select **OK** to open the **Sitelink** screen (Figure 3-5).
5. Select **Remote Support**.
6. Select **OK**.




Figure 3-5: Load Weighing Display Sitelink Screen Remote Support

The **Remote Support** screen opens (Figure 3-6).

7. Select **Support Desks Configuration**.
8. Select **OK**.




Figure 3-6: Load Weighing Display Remote Support Screen

The **Support Desks Configuration** screen opens (Figure 3-7).

9. Select **Add** .




Figure 3-7: Load Weighing Display Support Desks Configuration Screen

The virtual keypad shows on the **Support Desks Configuration** screen (Figure 3-8).

10. Enter the support desk number.




Figure 3-8: Load Weighing Display Support Desks Configuration Enter Support Desk Number

The **Desk Information Policy** screen opens (Figure 3-9).

11. Select the desk information policy for **Remote Control**, **Remote View**, and **File Transfer**.

Yes	Pairing is done without the consent of the machine operator
No	Disables the option
Ask	The operator must accept the pairing




Figure 3-9: Load Weighing Display Desk Information Policy

12. Select **OK**.

Sitelink3D

1. Select **Sitelink3D > Support Desk** on the Sitelink3D website to open the Sitelink3D **Support Desk** dialog (Figure 3-11).




Figure 3-10: Sitelink3D Support Desk on Menu

2. Select **Options** .



Figure 3-11: Sitelink3D Support Desk Dialog

The **Edit Support Desk** dialog opens (Figure 3-12).

3. Enter an **Auto-Pair PIN** and select **Save**.

EDIT SUPPORT DESK

Support Desk Number *

Identifying number of at least eight digits. For example, a phone number.

77644246

Allow auto-pairing

Auto-Pair PIN

Four digit number to confirm a pairing automatically.

1234

Meta Information

These settings are used by clients to pair with this desk.

Phone Number

migrate from

migrate_to

Pairing Tags

Clients will be asked to provide a value for each key listed here.

Save Cancel

Figure 3-12: Sitelink3D Edit Support Desk Dialog

A confirmation dialog opens on the load weighing display (Figure 3-13).

- Select **Skip** to send a pairing request to the remote support operator for approval.



NOTE

The status of the pairing request is pending until it is acknowledged on the Sitelink3D website.

- Select **OK** to enter an auto-pair PIN.




Figure 3-13: Load Weighing Display Auto-Pair PIN Dialog

When **OK** is selected, the **Auto-Pair PIN** screen opens (Figure 3-14).

- Enter the **Auto-Pair PIN**.




Figure 3-14: Load Weighing Display Auto-Pair PIN Screen

A confirmation dialog opens (Figure 3-15).

- c. Select **OK**.






Figure 3-15: Load Weighing Display Auto-Pair PIN Created and Approved

Make a Remote Support Request

1. Select **Setup**  to open the **Setup** menu (Figure 3-16).
2. Select **Remote Support** .




Figure 3-16: Load Weighing Display Setup Menu

The **Priority** screen opens (Figure 3-17).

3. Set the request priority, then select **OK**.




Figure 3-17: Load Weighing Display Priority Screen

The **Message** dialog opens (Figure 3-18).

4. Enter a brief description of the request using the virtual keyboard.




Figure 3-18: Load Weighing Display Message Dialog

The **Phone Number** dialog opens (Figure 3-19).

5. Enter a contact number using the virtual keyboard.




Figure 3-19: Load Weighing Display Phone Number Dialog

Dumper and Haul Truck Configuration

LM-100 can be configured for use with dumpers and haul trucks on the load weighing display.

The weighing procedure is the same as for a wheel loader. However, automatic region and product selection triggers were designed for the following actions:

Table 4-1:Load and Dump Auto Triggers

Load Trigger	Dumper and Haul Truck
Reverse	No
Timer	Yes
Manual	Yes
Dump Trigger	Dumper and Haul Truck
Bucket Sensor	No
Timer	Yes
Manual	Yes
Add to Total	Yes

Automatic Mode

To fully automate the load and/or dump actions, select a **Timer** auto trigger (see “Auto Triggers” on page 2-7).

1. Select the **Site** menu > **Metadata** > **Regions** on the Sitelink3D website.




Figure 4-1: Sitelink3D Site Menu

The **Metadata** screen opens with the **Regions** tab active.





Figure 4-2: Sitelink3D Metadata Regions

2. Select the appropriate region checkbox (Figure 4-3).
3. Select **Edit** .




Figure 4-3: Sitelink3D Region Selected

The **Edit Region** dialog opens (Figure 4-4). Each region used with the timer must have the **Usage** assigned either to **Load** or **Dump**.

4. Select the **Usage** for the region.

Load	When a machine is detected in a region with this usage assigned, a Timer auto trigger automatically selects the region and the associated product.
Dump	When a machine is detected in a region with this usage assigned, the timer starts when the machine is in the region but the dump region is selected after the system weighs the load.
n/a	This is not a load or dump region.




Figure 4-4: Sitelink3D Edit Region




NOTE

The **Timer Load** auto trigger does not work in a region with the usage set to **Dump**. Likewise, the **Timer Dump** auto-trigger does not work in a region with the usage set to **Load**.

Manual Mode

In **Manual** mode, the operator manually selects where the truck is loaded and where the material is dumped for the **Manual** auto-trigger to select the region and the product.

1. Select the **Manual** auto-trigger for **Load** and/or **Dump** (see “Auto Triggers” on page 2-7).

When the machine is detected in any region, **Load**  shows on the left side of the screen.







Figure 4-5: Load Weighing Display Load Active

Table 4-2: Load and Manual Dump Images

	<p>After selecting Load, the region and product associated with the load action are selected. The text “Load OK” shows momentarily under the Load image.</p>
	<p>When the machine is detected in another region, Load is active. This lets the operator select it if the prior selection was in error. If the region is correct, the load can be tipped. After the weighing action, Manual Dump is active on the left side of the display.</p>
	<p>After selecting Manual Dump, the text “Dump OK” shows momentarily under the Manual Dump image. The dump region is selected.</p>

Manual Mode with Regions Selection

When the machine operates within a region with the **Region Usage** assigned, **Load** is only active when the machine is detected inside the load region.

After entering the dump geofence region, **Manual Dump** is active after the weighing action.

**NOTE**

The **Manual Load** image does not show in the region when the **Usage** is set to **Dump**.

Add to Total Auto Trigger

The **Add To Total** trigger automatically selects the dump geofence region after the weight is added to the total (see “Auto Triggers” on page 2-7).

**NOTE**

For cases in which the machine operates in regions that have the **Usage** set to **Dump** and the material must be dropped onto the load region, the **Add To Total** auto-trigger overrides the **Usage** setting and correctly selects the region.

Weight Load Report

The Sitelink3D Report tool lets the user create reports for the completed jobs. The reports can be filtered by the time period and the reference data.

The Metadata database on the Sitelink3D website and the Reference Store on Loadmaster/Loadex systems contain the items listed on Table 5-1.

Table 5-1:Reference Data

Sitelink3D Metadata Item	Sitelink3D Metadata Group	Notes
Materials	Assets	Products in the LM-100/LX-100 Reference Store
Operators	Assets	Drivers in the LM-100/LX-100 Reference Store
Regions	Assets	Only editable on Sitelink3D
Shift Plans	Assets	Only editable on Sitelink3D
Customers	Load-Weighing	
Destinations	Load-Weighing	
Hauliers	Load-Weighing	Can be linked to one or more trucks
Locations	Load-Weighing	
Mixes	Load-Weighing	Two or more products
Notes	Load-Weighing	
Trucks	Load-Weighing	




Figure 5-1: Sitelink3D Metadata

Reference data can be created, edited, or deleted in the **Metadata** dialog on the Sitelink3D website. Reference data can be added and deleted on Loadmaster/Loadex systems only when the load weighing display is not connected to Sitelink3D. After a connection is made, reference data can only be added on Loadmaster/Loadex systems.

References are automatically synchronized between Sitelink3D and the load weighing display (see “Data Cloud Synchronization” on page 7-1).



NOTE

Data cannot be deleted from the load weighing display after the connection to Sitelink3D is established.

Create a Weight Load Report

1. Select **Site** menu > **Reports** on the Sitelink3D website to open the **Reports** dialog (Figure 5-3).




Figure 5-2: Sitelink3D Site Menu

2. Select **New Report**, then select **Weight Load Report**.





Figure 5-3: Sitelink3D Reports Menu

The **New Weight Load Report** dialog opens (Figure 5-4).

3. Enter a name and select the time period for the generated report.

The filters are disabled by default.

4. If necessary, select the radio button(s) to add filters.
5. Select **Edit**  to edit a filter.

The filters are **Machines, Materials, Mixes, Operators, Customers, Trucks, Hauliers, Load Regions in, Dump Regions Out, Destinations, Locations, and Notes.**

Figure 5-4: New Weight Load Report Dialog (Top)

A dialog with the name of the filter and available parameters opens (Figure 5-5).

6. Select the checkbox(es) of the parameters to edit.




Figure 5-5: Edit Filter

7. Select **Add** > to add the parameter.
8. Select **Remove** < to remove the parameter.
9. Select **Confirm** to close the **Edit Filter** dialog.
10. Select **Save** in the **New Weight Load Report** dialog.




Figure 5-6: New Weight Load Report Dialog (Bottom)

Sitelink3D generates the new report and the **Reports** dialog opens.




Figure 5-7: New Weight Load Reports Dialog

Work With Weight Load Reports

To use the report action options:

1. Select the appropriate checkbox on a report row.
2. Select the appropriate action:
 - Select **View** to see the report (Figure 5-8).
 - Select **Expand** to expand the report.
 - Select **View Material** to see material load and dump locations and the machine movement trail on the map for the selected job.
 - Select **Copy** to copy the report (with a new name).
 - Select **Download** to download the report on a spreadsheet.
 - Select **Archive** to archive the report.




Figure 5-8: View Weight Load Report

The report view expands.

Machine	Date	Start	End	Duration	Weight	Bucket Count	Material	Customer	Job Number	Ticket Number...
<input checked="" type="checkbox"/> PO 510	08/23/2023	3:19:49 PM	7:07:27 AM	39:47:39	9.92 Tonne	2			1899	0

Machine:	PO 510	Material:		Preset Tare:	0.00 Tonne
Date:	08/23/2023	Mix:		Price:	0.00 USD
Start:	3:19:49 PM	Operator:		Job Number:	1899
End:	7:07:27 AM	Customer:		Ticket Number:	0
Duration:	39:47:39	Truck:		Legal For Trade:	true
Distance:	30 km	Haul Truck:		Name:	Job
Weight:	9.92 Tonne	Hauler:		Attachment:	Bucket
Bucket Count:	2	Load Region In:			
		Dump Region Out:			
		Destination:			
		Location:			
		Note:			

Figure 5-9: Expanded Weight Load Report View

The material load and dump locations and machine movement trail show on the map.




Figure 5-10: Machine Movement, Load, and Dump Locations

3. If necessary, select **Summaries** to see a summary of the report.

The screenshot shows a software interface for a 'Weight Load Report'. At the top, there's a header with 'Machines' and a lock icon, followed by '1 - Weight Load Report' with a close button. Below this, there are filters for 'Total by Machine', a date range from '08/23/2023 8:38:23 AM' to '08/30/2023 8:38:23 AM', and a 'View' dropdown menu. The 'View' menu is open, showing 'All' and 'Summaries' (highlighted). Other filters include 'Group By: Machine' and 'Operation: Total'. Below the filters is a table with columns: Name, Bucket Cou..., Weight, Duration, Price, and a search icon. The table contains two rows of data.

Name	Bucket Cou...	Weight	Duration	Price
PO 510	99	367.57 Tonne	3:05:46	0.00 USD
PO431	62	309.30 Tonne	2:15:12	0.00 USD

Figure 5-11: Weight Load Report Summary

Live Statistics Loader Widgets

Live statistics loader widgets are used to monitor the machine performance and product movement.



NOTE

A widget is an element of a graphical user interface that shows information or provides a specific way for a user to interact with the operating system (OS) or an application.

1. Select **Loader**  on the Sitelink3D website to open the **Live Statistics** pane (Figure 6-2).




Figure 6-1: Select Loader Widget

2. Select **New**.




Figure 6-2: Select New Loader Widget

The **New Loader Widget** menu opens (Figure 6-3).

3. Select the appropriate widget type.

Weight Region Summary	Summarizes the region, survey weight, the desired shift plan, and the desired target for the widget (refer to “Weight Region Summary Widget Creation” on page 6-2)
Weight Summary	Summarizes all or a selection of the machines, materials, customers, destinations, hauls, hauliers, locations, mixes, notes, operators, trucks and/or reporting range for the widget (refer to “Weight Summary Widget Creation” on page 6-5)
Weight Contract Summary	Summarizes all or a selection of the weight contract, destinations, notes, reporting range, and/or targets for the widget (refer to “Weight Contract Summary Widget Creation” on page 6-9)




Figure 6-3: New Loader Widget Menu

Weight Region Summary Widget Creation

1. Select **Weight Region Summary** from the **New Loader Widget** menu to open the **New Weight Region Summary Widget** screen (Figure 6-4 on page 6-3).
2. Enter a **Title** for the widget.
3. Select a **Region** from the dropdown list.
4. Enter a **Survey Weight** for the region.
5. Select a **Shift Plan** for the generated widget.
6. Select the radio button for the type of **Shift Plan**:
 - **Most recently started shift.**
 - **Shifts starting since:**
Select the starting date from the dropdown list.
 - **Shifts starting between:**
Select the start date and the end date.

7. Select the target (**Total Weight**, **Total Loads In**, and **Total Loads Out**).
8. Select the **Color Band Type** (**Asymmetric** or **Symmetric**).


The screenshot shows the configuration interface for a 'NEW LIVE STATISTICS WIDGET'. The interface is divided into several sections:

- Title *:** A text input field and a 'Color' selection button (blue).
- Weight Region Summary:**
 - Region *:** A dropdown menu currently showing '-- No item selected --'.
 - Survey Weight *:** A text input field with '0.00' and a 'Tonne' unit selector.
- Reporting Range *:**
 - Shift Plan *:** A dropdown menu showing '24/7'.
 - Most recently started shift *:** A radio button option.
 - Shifts starting since *:** A radio button option with a 'Start of last' dropdown menu set to 'Sunday'.
 - Shifts starting between *:** A radio button option with 'Start of' and 'To start of' dropdown menus, both set to 'Europe/London'.
- Targets:**
 - Dynamic Target(s):** A section with a plus icon and a message: 'Updated as the shift progresses.' Below it are three target options: 'Total Weight', 'Total Loads In', and 'Total Dumps Out'.
 - Color Band Type:** Two radio button options: 'Asymmetric' (selected) and 'Symmetric'.
 - Gauge Preview:** A preview area showing a blue gauge with a message: 'A target must be provided in order for the gauge to render. Numerical data will be shown instead.' Below it is a 'Target' text input field with a 'Tonne' unit selector.

At the bottom right, there are 'Save' and 'Cancel' buttons.


Figure 6-4: New Weight Region Summary Widget

If the **Color Band Type** is Asymmetric, the **Gauge Preview** shows (Figure 6-5 on page 6-4).

9. Set the target value using the **Increment/Decrement**  control.



NOTE

The target value must be set for the **Add**  to become active.

10. Select **Add**  to set tolerances.

Figure 6-5: Gauge Preview



NOTE

Enter a **Survey Weight** of 0 to monitor an initially empty region/bay.

11. Select **Save** on the **New Weight Region Summary Widget** screen (Figure 6-4 on page 6-3).

The new **Weight Region Summary** widget opens.





Figure 6-6: Weight Region Summary Widget

Weight Summary Widget Creation

1. Select **Weight Summary** from the **New Loader Widget** menu to open the **New Weight Summary Widget** dialog (Figure 6-7).
2. Enter a **Title** for the widget.

Figure 6-7: New Weight Summary Widget (Top)

3. Select **Select Filter**  to select filters (Figure 6-8):
 - In the **Weight Summary** group, select up to ten **Machines** and **Materials** filters.
 - In the **Customers, Destinations, Hauls, Hauliers, Locations, Mixes, Notes, Operators, and Trucks** groups, select up to ten filters.
4. Select **Confirm**.

Name	Code	Time	Target
<input type="checkbox"/> Truck 1		10.1	20
<input type="checkbox"/> Truck 3		12.6	29
<input type="checkbox"/> Truck 5		0	0

Name	Code	Time	Target
<input type="checkbox"/> Truck 2		9.6	20.5
<input type="checkbox"/> Truck 4		0	0

Figure 6-8: New Weight Summary Widget Filter Selection

5. Select the radio button for the type of **Shift Plan** (Figure 6-9 on page 6-6):
 - **Most recently started shift.**
 - **Shifts starting since:**
Select the starting date from the dropdown list.
 - **Shifts starting between:**

Select the start date and the end date.

Reporting Range *

Shift Plan *

Define Shift Plans in the Metadata.

24/7 ▼

Most recently started shift *

Shifts starting since *

Start of last

Sunday ▼

Shifts starting between *

Start of To start of

Europe/London Europe/London

Figure 6-9: New Weight Summary Widget Shift Plan

6. Select the dynamic target (**Total Active Loaders, Weight, Total Bucket Count, Total Loads Completed, Total Distance, and Total Duration**) (Figure 6-10 on page 6-7).
7. Select the static target (**Ave Weight per Bucket Count, Ave Weight per Load, Ave Bucket Count per Load, Ave Distance per Load, Ave Duration per Load, Ave Weight per Hour, Ave Load per Hour, and Ave Bucket Count per Hour**).



NOTE

If the widget is saved with no filters selected, the default is to select all filter entries. See “Weight Load Report” on page 5-1 for filtering options.

8. Select the **Color Band Type (Asymmetric or Symmetric)**.

Targets

+ **Dynamic Target(s)**

i Updated as the shift progresses.

Total Active Loaders

Total Weight

Total Bucket Count

Total Loads Completed

Total Distance

Total Duration

+ **Static Target(s)**

i Remains constant throughout the shift.

Ave. Weight per Bucket Count

Ave. Weight per Load

Ave. Bucket Count per Load

Ave. Distance per Load

Ave. Duration per Load

Ave. Weight per Hour

Ave. Load per Hour

Ave. Bucket Count per Hour

Color Band Type
 Asymmetric Symmetric

Gauge Preview

i A target must be provided in order for the gauge to render. Numerical data will be shown instead.

+

Target

+

Save
Cancel

Figure 6-10: New Weight Summary Widget (Bottom)

If the **Color Band Type** is Asymmetric, the **Gauge Preview** shows (Figure 6-11).

9. Set the target value using the **Increment/Decrement**  control.



NOTE

The target value must be set for the **Add**  to become active.

10. Select **Add**  to set tolerances.




Figure 6-11: Gauge Preview



NOTE

Enter a **Survey Weight** of 0 to monitor an initially empty region/bay.

11. Select **Save** (Figure 6-10 on page 6-7).

The new **Weight Summary** widget opens.



Figure 6-12: Weight Summary Widget

Weight Contract Summary Widget Creation


1. Select **Weight Contract Summary** from the **New Loader Widget** menu to open the **New Weight Contract Summary Widget** dialog (Figure 6-13).
2. Enter a **Title** for the widget.
3. Enter the **Contract Weight**.
4. Enter the **Average Weight per Truck**.

The screenshot shows the 'NEW LIVE STATISTICS WIDGET' dialog box. It contains the following fields and sections:

- Title ***: A text input field.
- Color**: A color selection button (blue).
- Weight Contract Summary**: A section header.
- Contract Weight ***: A text input field with the value '200.00' and a 'Tonne' unit selector.
- Average Weight per Truck ***: A text input field with the value '20.00' and a 'Tonne' unit selector.
- Destinations**: A section header with a 'Selected Destinations (0 of 10 allowed)' field and an edit icon.
- Notes**: A section header with a 'Selected Notes (0 of 10 allowed)' field and an edit icon.

Placeholder text 'No results found' is visible below the Destinations and Notes sections.

Figure 6-13: Weight Contract Summary Widget (Top)

5. Select **Edit**  to select filters (Figure 6-14):
 - In the **Destinations** and **Notes** groups, select up to 10 filters.
6. Select **Confirm**.




Figure 6-14: Weight Contract Summary Filter Selection

7. Select the radio button for the type of shift plan (Figure 6-15):
 - **Most recently started shift.**
 - **Shifts starting since:**
Select the starting date from the dropdown list.
 - **Shifts starting between:**
Select the start date and the end date.

Figure 6-15: New Weight Summary Widget Shift Plan

8. Select the dynamic target (**Total Bucket Count**, **Total Loads Completed**, and **Total Load Duration**) (Figure 6-16).
9. Select the static target (**Ave Number of Trucks to Load**).



NOTE

If the widget is saved with no filters selected, the default is to select all filter entries. See “Weight Load Report” on page 5-1 for filtering options.

10. Select the **Color Band Type (Asymmetric or Symmetric)**.






Figure 6-16: Weight Contract Summary Widget (Bottom)

If the **Color Band Type** is Asymmetric, the **Gauge Preview** shows (Figure 6-17).

11. Set the target value using the **Increment/Decrement**  control.



NOTE

The target value must be set for the **Add**  to become active.

12. Select **Add**  to set tolerances.




Figure 6-17: Gauge Preview

**NOTE**

Enter a **Survey Weight** of 0 to monitor an initially empty region/bay.

13. Select **Save** (Figure 6-16 on page 6-11).

The new **Weight Contract Summary** widget opens.





Figure 6-18: Contract Weight Summary Widget

Live Statistics Haul Summary Widget Creation



The live statistics Haul Summary widget is used to monitor the machine performance and product movement.

1. Select **Haul Summary** from the **New Hauler Widget** menu to open the **New Hauler Widget** dialog (Figure 6-19).
2. Enter a **Title** for the widget.

Figure 6-19: New Haul Summary Widget (Top)

3. Select **Edit**  to select filters (Figure 6-20 on page 6-13):
 - In the **Haul Summary** group, select the **Load Region**, **Dump Region**, **Material**, and **Material Unit System** (optional) filters.
4. Select the appropriate **Machines** radio button.

The default selection is **Do not restrict by Machines**.

- If **Restrict by the following Machines...** is selected, select **Edit**  to select up to 10 **Machines**.
5. Select the appropriate **Operators** radio button.
The default selection is **Do not restrict by Operators**.
- If **Restrict by the following Operators...** is selected, select **Edit**  to select up to 10 **Operators**.
6. Select **Confirm**.




Figure 6-20: New Haul Summary Filter Selection

7. Select the radio button for the type of **Shift Plan** (Figure 6-21):
 - **Most recently started shift.**
 - **Shifts starting since:**
Select the starting date from the dropdown list.
 - **Shifts starting between:**
Select the start date and the end date.

The screenshot shows a form titled "Reporting Range *" with a "Shift Plan *" section. Below the title is a link "Define Shift Plans in the Metadata." and a dropdown menu showing "24/7". There are three radio button options:

- Most recently started shift ***
- Shifts starting since ***: This option has a "Start of last" dropdown menu showing "Sunday".
- Shifts starting between ***: This option has two date input fields labeled "Start of" and "To start of", both with "Europe/London" as the time zone.

Figure 6-21: New Haul Summary Widget Shift Plan

8. Select the dynamic target (**Bed Loads, Bed Dumps, and Total Material Hauled**) (Figure 6-22).
9. Select the static target (**Ave Time Loaded, Ave Distance Loaded, Ave Time Empty, Ave Time Cycle, and Ave Distance Cycle**).
10. Select the **Color Band Type** (**Asymmetric** or **Symmetric**).

The screenshot shows a configuration window titled "Targets". It has two main sections: "Dynamic Target(s)" and "Static Target(s)".


- Dynamic Target(s):** This section is updated as the shift progresses. It includes a list of targets: "Bed Loads", "Bed Dumps", and "Total Material Hauled". The "Total Material Hauled" target is currently selected.
- Static Target(s):** This section remains constant throughout the shift. It includes a list of targets: "Ave. Time Loaded", "Ave. Distance Loaded", "Ave. Time Empty", "Ave. Distance Empty", "Ave. Time Cycle", and "Ave. Distance Cycle". The "Ave. Time Loaded" and "Ave. Distance Loaded" targets are currently selected.
- Color Band Type:** A dropdown menu is set to "Asymmetric".
- Gauge Preview:** A preview area showing a warning message: "A target must be provided in order for the gauge to render. Numerical data will be shown instead." There are plus signs (+) next to the dynamic and static target lists, suggesting they can be expanded.
- Buttons:** "Save" and "Cancel" buttons are located at the bottom right of the window.

Figure 6-22: New Haul Summary Widget (Bottom)


If the **Color Band Type** is Asymmetric, the **Gauge Preview** shows (Figure 6-5 on page 6-4).

11. Set the target value using the **Increment/Decrement**  control.



NOTE The target value must be set for the **Add**  to become active.

12. Select **Add**  to set tolerances.



The image shows a configuration window for a gauge. At the top, there are two tabs: 'Asymmetric' (selected) and 'Symmetric'. To the right is a 'Gauge Preview' showing a semi-circular gauge with a needle pointing to 0. Below this are several rows of configuration options:

- A red bar representing the range '6.06 ~ +∞' with a blue '+' button to its right.
- A red bar representing the range '6 ~ 6.06' with an input field containing '1', a '%' symbol, and a red 'X' button.
- A 'Target' field containing the value '6' with an up/down arrow icon.
- A red bar representing the range '5.94 ~ 6' with an input field containing '-1', a '%' symbol, and a red 'X' button.
- A red bar representing the range '-∞ ~ 5.94'.

At the bottom right of the configuration area is another blue '+' button.

Figure 6-23: Gauge Preview



NOTE Enter a **Survey Weight** of 0 to monitor an initially empty region/bay.

13. Select **Save** (Figure 6-22 on page 6-14).

The new **Haul Summary** widget opens.




Figure 6-24: Haul Summary Widget

Data Cloud Synchronization

Automatic References Synchronization

Metadata references that were created, amended, or deleted on the Sitelink3D website are automatically synchronized each time the load weighing display joins a new site using any of the three methods described in “Ways to Join a Site” on page 2-13. Once the device has joined the site, a progress bar shows while the references are downloaded.






Figure 7-1: Load Weighing Display Synchronization

After the initial references update, the system automatically updates them each time the system reconnects to the internet. This can take longer than the typical bootup process after the power is turned ON. The progress bar shows briefly twice. It is possible to select specific references to be synchronized at startup or to disable synchronization.

1. Select **Setup**  to open the **Setup** menu.
2. Select **Technician Level Settings** .
3. If necessary, use the virtual keypad to enter a valid PIN, then select **ENT**.

The default technician level settings PIN is 1234.

The **Technician Level Settings** menu opens.

4. Select **Sitelink**, then select **OK** to open the **Sitelink** screen (Figure 7-2).
5. Select **Metadata auto-pull**, then select **OK**.




Figure 7-2: Load Weighing Display Sitelink Screen

The **Metadata auto-pull** screen opens (Figure 7-3).

6. Select the appropriate reference categories, then select **OK**.

If none are selected, the references are not synchronized at startup.

Any changes made to the Sitelink3D Metadata are automatically uploaded to online Loadmaster/Loadex systems during the synchronization at startup. This captures Metadata changes made while the load weighing display was OFF.




Figure 7-3: Load Weighing Display Sitelink Metadata Auto-Pull

Manual Reference Synchronization

1. Open the load weighing display main screen (Figure 7-4).
2. Select the appropriate reference(s).

For example, select **Products**, **Trucks**, **Regions**, and etc., to manually synchronize references.




Figure 7-4: Load Weighing Display Main Screen

The **Product** screen opens (Figure 7-5).

3. Select **Refresh** .





Figure 7-5: Load Weighing Display Product Screen

Add Reference Data on the Load Weighing Display

When a new reference is created in Loadmaster/Loadex, it automatically synchronizes with the cloud when the load weighing display is on-line.

1. Open the load weighing display main screen.
2. Select the appropriate reference to open the **Product** screen (Figure 7-6).
3. Select **Add** .




Figure 7-6: Load Weighing Display Product Screen

Site Key Expiration

The maximum number of days of Site PIN validity is 365. After the set period expires, the **Enter Site Access PIN** dialog shows on the load weighing display (Figure 7-7).

If **ESC** is selected, the device will start normally but it will not connect to the cloud. All weighing activity will be saved and synchronized with Sitelink3D when the device is reconnected. The **Enter Site Access PIN** dialog shows at every startup until a valid PIN is entered.

If the operator selects **OK**, the operator must then enter a valid site PIN to connect the device to Sitelink3D.



Figure 7-7: Load Weighing Display Enter Site Access PIN

Safety Warnings

General Warnings

1. Read and become familiar with the machine manufacturer's operator's manual, including safety information, before installing or using Topcon components.
2. Use extreme caution on the job site. Working around heavy construction equipment can be dangerous.
3. DO NOT attach Topcon brackets, cables, or hose connections while the machine is running.
4. DO NOT allow any Topcon components to limit the visibility of the operator.
5. Use cable ties to keep hoses and cables secured, and away from possible wear or pinch points.
6. Use eye protection when welding, cutting, or grinding on the machine.
7. Protect yourself at all times, and wear protective clothing when working on or near hydraulic lines. Hydraulic lines can be under extreme pressure, even when the machine is turned off.



DANGER

Relieve all pressure in the hydraulic lines before disconnecting or removing any lines, fittings, or related components. If injury occurs, seek medical assistance immediately.



CAUTION

When welding, use appropriate precautions and practices. After welding, all affected areas should be painted with a rust inhibitor.



DANGER

Disconnect all Topcon system electrical cables prior to welding on the machine.



DANGER

DO NOT weld near hydraulic lines or on any equipment when in operation.



CAUTION

All mounting bracket welds must be secure and strong to prevent the sensor equipment from vibrating excessively, or from detaching at the weld during operation.

This product should never be used:



CAUTION

- Without the operator thoroughly understanding the Operator's Manual and Quick Reference Guide.
 - After disabling safety systems or altering the product.
 - With unauthorized accessories.
 - Without proper safeguards at the job site.
 - Contrary to applicable laws, rules, and regulations.
-



WARNING

TPS products should never be used in dangerous environments. Use in rain or snow for a limited period is permitted.

**WARNING**

Tampering with the unit by the operator or non-factory authorized technicians will void the unit's warranty:

- Do not attempt to open the unit and modify any of its internal components.
 - Do not short circuit.
-



www.topconpositioning.com

